總公司:11071 台北市信義區忠孝東路四段560號5樓 端路点: 11072 台北市信義 匹基 隆路 一段 176 號 3 樓、4 樓 電話: 02-2758-8418 2756-2200(代表號)

免費申訴電話:0809-005607

人可透過本公司免費服務電話(0800-010850)、網站(https://www.south-china.com.tw)或總、分公司及其他分支機構查閱公開資訊文件。 本商品經本公司合格簽署人員檢視其內容業已符合保險精算原則及保險法令,惟為確保權益,基於保險業與消費者衡平對等原則,消費者仍應詳加閱讀保險單條款與相關文件,審慎選擇保險商品。本商品如有虛偽不實或違法情事,應由本公司及負責人依法負責。 ※本商品受保險安定基金之保障 ※詳細承保內容以保單條款為準。

South China Insurance Hot Works Warranty

111.01.07(111)華產企字第 009 號函備查

It is a condition precedent to the liability of the Company that when welding or flame-cutting equipment, blowlamps, blowtorches, hot air guns and/or any other equipment producing heat ("the equipment") are used by the Assured the Assured shall ensure that

a. Before hot work commences:

- * a permit to work is issued by a trained and competent person, this permit is to be issued when all procedures relating to the safety of the hot work operation have been carried out and accepted within any enclosed space(limited ventilated area within the confines of the vessel) where this possibility of explosive vapours exists, a competent chemist will issue a gas free certificate for that space
- * a fire control centre is established, active and manned throughout each period of work as defined in the permit to work
- * the first plan and any specific work procedures are brought to the attention of all employees and subcontractors.
- * where practical, the vessel's permanent fire-fighting systems are either partially or wholly activated.

b. Before using the equipment:

- *at the start of each working shift, each item of the equipment shall be examined for defects and any defects repaired or replaced.
- *all movable combustible materials (including cylinders or canisters for use but not connected up to equipment) or residues are removed from the vicinity of the work and all gases and vapours removed. Fixed combustible materials shall be kept wetted down or suitably protected with incombustible materials.
- *pipelines in the work area and in the vicinity of the work area are isolated by blanking, plugging or disconnecting
- *suitable portable fire extinguishing apparatus will be kept ready for immediate use as near as practicable to the scene of the work together with a person trained and competent in its use.
- *the fire main is charged and hoses (controllable at the nozzle) are connected up in readiness for immediate use and tested prior to the commencement of the work.

c. During use of the equipment:

*the lighting and use of the equipment shall be carried out strictly in accordance with the manufacturer's instructions.

華南金融集團

伊華南產物保險股份有限公司 SOUTH CHINA INSURANCE CO., LTD.

總公司:11071 台北市信義區忠孝東路四段560號5樓聯絡處:11072 台北市信義區基隆路一段176號3樓、4樓電話:02-2758-8418 2756-2200(代表號) 免費申訴電話:0809-005607

※要保人可透過本公司免費服務電話(0800-010850)、網站(https://www.south-china.com.tw)或總、分公司及其他分支機構查閱公開資訊文件。 ※本商品經本公司合格簽署人員檢視其內容業已符合保險精算原則及保險法令,惟為確保權益,基於保險業與消費者衡平對等原則,消費者仍 應詳加閱讀保險單條款與相關文件,審慎選擇保險商品。本商品如有虛偽不實或違法情事,應由本公司及負責人依法負責。 ※詳細承保內容以保單條款為準。 ※本商品受保險安定基金之保障。

- *the equipment is lit for as short a time as possible before use and extinguished immediately after use and is not left unattended whilst alight.
- *blow lamps are filled and gas or fuel cylinders or canisters are changed in the open.
- *a responsible person shall act as fire watcher at each area of hot work.
- d. A continuous fire safety check is made in the work area and in the vicinity of the work area for a period of thirty minutes after completion of each period of work and periodically thereafter until all likelihood of ignition has passed.